


**C509**

**LF SEAT CONTROL SWITCH**

| PIN | CIRCUIT | CIRCUIT FUNCTION |
|---|---|---|
| 1 | 980 (YE/WH) | Seat Switch to Horizontal Motor-LH |
| 2 | 979 (RD/LB) | Seat Switch to Front Height Motor-LH |
| 3 | 978 (YE/LB) | Seat Switch to Front Height Motor-LH |
| 4 | 272 (WH/OG) | Memory Switch LED Drive |
| 5 | 270 (BN/OG) | Set Switch |
| 6 | 267 (BN/LG) | Memory Switch #1 |
| 7 | 268 (BK/OG) | Memory Switch #2 |
| 8 | – | NOT USED |
| 9 | 981 (RD/WH) | Seat Switch to Horizontal Motor-LH |
| 10 | 797 (LG/VT) | Power (Hot at All Times) |
| 11 | 982 (YE/LG) | Seat Switch to Rear Height Motor-LH |
| 12 | 983 (RD/LG) | Seat Switch to Rear Height Motor-LH |
| 13 | 918 (GY) | Seat Switch to Recliner Motor-LH |
| 14 | 919 (GY/BK) | Seat Switch to Recliner Motor-LH |

**CONNECTOR REFERENCE LIST**

| CONNECTOR | SECTION-PAGE |
|---|---|
| C520 | 57-3 |
| C521 | 57-3 |