

C941
RIGHT POWER SLIDING DOOR SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	–	NOT USED
2	–	NOT USED
3	1238 (TN/LB)	Right Power Sliding Door Switch Feed
4	1205 (BK)	Ground
5	–	NOT USED
6	–	NOT USED



C942
LEFT POWER SLIDING DOOR SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	–	NOT USED
2	–	NOT USED
3	1238 (TN/LB)	Left Power Sliding Door Switch Feed
4	1205 (BK)	Ground
5	–	NOT USED
6	–	NOT USED

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C211	130-5
C216	14-4
C341	59-12
C342	59-13
C915	102-2