
1 2 3 4 5 6 7 8 9 10
A B C D E F
C157 FUEL INJECTOR #2
C158 FUEL INJECTOR #3
C156 FUEL INJECTOR #1
C140 CRANKSHAFT POSITION (CKP) SENSOR
C159 FUEL INJECTOR #4
C134 STARTER MOTOR/ SOLENOID
C152 HEATED OXYGEN SENSOR (HO2S) #21
C106 RIGHT ELECTRIC COOLING FAN MOTOR
C160 FUEL INJECTOR #5
C107 LEFT ELECTRIC COOLING FAN MOTOR
C161 FUEL INJECTOR #6
DO NOT USE THIS ILLUSTRATION AND GRID FOR REPORTING VEHICLE REPAIR LOCATIONS
FRONT OF VEHICLE
WINDSTAR
FCS–12255–01 (3 OF 11)

ENGINE (3 OF 4)