-3

C14 (BN)

14401



F11012

P91
Central Junction
Box (CJB)

Pin	Circuit	Circuit Function
1	32-KA15 (WH/BK)	Switched between: Battery voltage, Ground or Open
2	32-KA19B (WH/BK)	Switched between: Battery voltage, Ground or Open
3	32-KA19 (WH/BK)	Switched between: Battery voltage, Ground or Open
	32-KA15A (WH/BK) +	Switched between: Battery voltage, Ground or Open
	32-KA19 (WH/BK)	Switched between: Battery voltage, Ground or Open
4	31-DA1 (BK)	Ground
5	31S-KA14A (BK/GN)	Ground, switched
6	32-KA11A (WH/BK)	Switched between: Battery voltage, Ground or Open
7	29-LC6 (OG/BK)	Voltage supplied at all times (overload protected)
	29-LC1 (OG/BU)	Voltage supplied at all times (overload protected)
	29-LC7 (OG/BU)	Battery voltage, hot at all times (overload protected)
8	29S-GJ1 (OG/BU)	Voltage supplied at all times (overload protected), switched
9	–	not used
10	32-KA9 (WH/BU) +	Switched between: Battery voltage, Ground or Open
	32-KA9A (WH/BU)	Switched between: Battery voltage, Ground or Open
	32-KA9B (WH/BU)	Switched between: Battery voltage, Ground or Open
11	32-KA28 (WH/RD)	Switched between: Battery voltage, Ground or Open