C205b

14401

N113
Main light switch



F06209

Pin	Circuit	Circuit Function
1	1045 (DB/WH)	Illumination dimmer, output
2	1008 (LG/OG)	Interior lamp relay, control
3	–	not used
4	57 (BK)	Ground
5	–	not used
6	14 (BN)	Power, Exterior lamps

C207 (BK)

14401

N434
Luggage compartment lid release switch



F02185

Pin	Circuit	Circuit Function
1	913 (GY/RD)	Luggage compartment switch, to luggage compartment solenoid
2	84 (VT/YE)	Voltage supplied at all times (overload protected)