14398 - S8

Splice Location: **C8** - Below Battery Junction Box (BJB)

13 to Auxiliary Junction Box (AJB)
13 to Auxiliary Junction Box (AJB)
13 to Battery Junction Box (BJB)
13 to Battery Junction Box (BJB)
13 to Splice 14401-S21
13 to Daytime Running Lamp (DRL) module

14398 - S9

Splice Location: **G6** - Engine Compartment, LH Side Front

14 to Side lamp, left front
14 to Park/turn lamp, left front
14 to Splice 14401-S12
14 to Side lamp, right front
14 to Park/turn lamp, right front

14398 - S10

Splice Location: **A3** - Near Thermo Expansion Valve (TXV) T/O (C1373)

359 to Powertrain Control Module (PCM)
359 to 14407 Fuel tank unit
359 to Mass Air Flow (MAF) sensor
359 to 14324 Power steering pressure switch

14398 - S11

Splice Location: **G4** - Engine Compartment, Center Front

307 to Powertrain Control Module (PCM)
307 to Speed control actuator
307 to Redundant pedal switch (with IVD)
307 to ABS control module
307 to Brake pressure switch (less IVD)

14398 - S12

Splice Location: **C8** - Below Battery Junction Box (BJB)

679 to Powertrain Control Module (PCM)
679 to Splice 14401-S18
679 to Windshield wiper motor

14398 - S14

Splice Location: **D8** - Below Battery Junction Box (BJB)

1050 to Battery Junction Box (BJB)
1050 to Battery Junction Box (BJB)
1050 to Battery Junction Box (BJB)

14398 - S15

Splice Location: **A7** - Near Brake Fluid Level Switch T/O (C124)

460 to Splice 14A488-S63
460 to 14401 Air bag sliding contact
460 to Battery Junction Box (BJB)

14398 - S19

Splice Location: **B1** - Near Auxiliary Relay Box (AJB) (F4), RH Side

1140 to Powertrain Control Module (PCM)
1140 to Powertrain Control Module (PCM)
1140 to Mass Air Flow (MAF) sensor
1140 to Battery Junction Box (BJB)
1140 to Battery Junction Box (BJB)

14398 - S20

Splice Location: **G4** - Engine Compartment, Center Front

12 to High beam lamp, left front
12 to High beam lamp, right front
12 to Battery Junction Box (BJB)
12 to Battery Junction Box (BJB)

14398 - S21

Splice Location: **E8** - Near Low Pitch Horn T/O (C1261)

511 to Powertrain Control Module (PCM)
810 to ABS control module

14398 - S23

Splice Location: **G8** - Near High Beam Lamp, Left front T/O (C1020)

2 to Park/turn lamp, right front
2 to 14A488
2 to Splice 14401-S16

14398 - S24

Splice Location: **B8** - Near Battery Junction Box (BJB)

3 to Park/turn lamp, left front
3 to 14A488
3 to Splice 14401-S10

14398 - S25

Splice Location: **F8** - Near High Beam Lamp, Left Front T/O (C1020)

6 to Battery Junction Box (BJB)
6 to Horn, high pitch
6 to Horn, low pitch

Note: T/O = Take Out