Window operating switch, driver side front (multiple) -11

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Left front window circuit	4 (C486) and 12 (C487)	Off	Open circuit
		Down	Open circuit
		Driver window one–touch down	Closed circuit
	4 (C486) and 11 (C487)	Off	Open circuit
		Down	Closed circuit
		Driver window one–touch down	Closed circuit
	4 (C486) and 9 (C487)	Off	Open circuit
		Up	Closed circuit
	9 (C487) and 3 (C486)	Off	Closed circuit
		Up	Open circuit
Right front window circuit	4 (C486) and 1 (C487)	Off	Open circuit
		Up	Closed circuit
		Down	Open circuit
	4 (C486) and 4 (C487)	Off	Open circuit
		Up	Open circuit
		Down	Closed circuit
	1 (C487) and 3 (C486)	Off	Closed circuit
		Up	Open circuit
		Down	Closed circuit
	4 (C487) and 3 (C486)	Off	Closed circuit
		Up	Closed circuit
		Down	Open circuit
Left rear window circuit	2 (C486) and 15 (C487)	Off	Open circuit
		Up	Closed circuit
		Down	Open circuit
	2 (C486) and 16 (C487)	Off	Open circuit
		Up	Open circuit
		Down	Closed circuit
	3 (C486) and 15 (C487)	Off	Closed circuit
		Up	Open circuit
		Down	Closed circuit
	3 (C486) and 16 (C487)	Off	Closed circuit
		Up	Closed circuit
		Down	Open circuit
Right rear window circuit	2 (C486) and 7 (C487)	Off	Open circuit
		Up	Closed circuit
		Down	Open circuit
	2 (C486) and 8 (C487)	Off	Open circuit
		Up	Open circuit
		Down	Closed circuit
	3 (C486) and 7 (C487)	Off	Closed circuit
		Up	Open circuit
		Down	Closed circuit
	3 (C486) and 8 (C487)	Off	Closed circuit
		Up	Closed circuit
		Down	Open circuit
Rear window cutoff circuit	2 (C486) and 1 (C486)	Off	Open circuit
		Up	Closed circuit