
Hot in Run/Start
F2.30
5A
Central Junction Box (CJB) (14A067)
Hot at all times
F1.33
30A
Battery Junction Box (BJB)
Hot in Run/Start
F2.10
10A
Central Junction Box (CJB) (14A067)
Auxiliary A/C relay
Auxiliary temperature actuator (19E616)
Forces air through auxiliary A/C-heater registers
Auxiliary blower motor
Limits the amount of current to the blower motor to provide various fan speeds.
Auxiliary blower motor resistor assembly
Auxiliary function selector switch assembly, rear
Front auxiliary A/C switch
Auxiliary mode actuator