66-5 WARNING CHIME



C260

BELT MINDER MODULE

PIN	CIRCUIT	CIRCUIT FUNCTION
1	640 (RD/YE)	Ignition (Hot in Start or Run)
2	–	NOT USED
3	–	NOT USED
4	57 (BK)	Ground



C261

BELT MINDER MODULE

PIN	CIRCUIT	CIRCUIT FUNCTION
1	871 (YE)	Fasten Belts Indicator Output
2	85 (BN/LB)	Safety Belt Warning Switch Input
3	679 (GY/BK)	VSS (+)
4	14 (BN)	Park Lamp Relay Ground