F26, F27

-10


30
F26
65A
30
F27
45A
P93
Battery Junction
Box (BJB)
30) Hot at all
times
DA07
8 WH/BU
DA19
3 WH/RD
2
1
C202
P91
Central Junction
Box (CJB)
3
6
C230
K304
Front blower motor
relay
F45
15A
F47
15A
5
7
C231
K1
Rear window de-
frost relay