4.6L



CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C192	23-12, 24-12
C294	23-11, 24-10, 25-11

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.