
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C1010
C130
A/C clutch cycling pressure switch (19D594)
C1066
Idle Air Control (IAC) valve (9F715)
C1184
Fuel injector 4 (9F593)
C1196
Ignition transformer capacitor
C124
Brake fluid level switch (2L414)
C140
14305
C1035a
Battery Junction Box (BJB) (14A003)
14290
C146
C1100b
Battery (10655)
G104
14B060
C1021
Headlamp, left (13008)
C160
Wheel speed sensor, right front (2C204)
C1262
Constant Control Relay Module (CCRM)
9D930
12A581
C1043
Park/turn lamp, right front (13411)
C14290
C1072
EGR vacuum regulator solenoid (9J459)
C180
Camshaft position sensor (6B288)
C102b
Generator
C102a
Generator
front of vehicle
3.8L engine