
1
2
3
4
5
6
7
8
A
B
C
D
E
F
C1045
C1066
Idle Air Control (IAC) valve (9F715)
C1184
Fuel injector 4 (9F593)
12B637
C1312
Fuel injector 7 (9F593)
C1185
Fuel injector 5 (9F593)
C115
Coil On Plug (COP) 5 (12A366)
C189
Throttle Position Sensor (TPS) (9B989)
C122
Speed control servo (9C735)
C106
Fuel rail pressure transducer sensor
C1064
Engine Coolant Temperature (ECT) sensor (12A648)
C137
Windshield washer pump motor (17618)
C145
14290
C101
Crankshaft position sensor (6C315)
C180
Camshaft position sensor (6B288)
14B060
G104
front of vehicle

Cobra