C432 (BK)

9D866



F02085

14A005



F02113

C434 (BK)

14407

B19
Fuel sender



F04075

Pin	Circuit	Circuit Function
1	–	not used
2	29 (YE/WH)	Fuel pump/fuel gauge sender
3	398 (BK/YE)	Ground
4	–	not used

C435

14407

B113
Fuel tank pressure transducer sensor



F03093

Pin	Circuit	Circuit Function
1	351 (BN/WH)	Reference, voltage
2	359 (GY/RD)	signal, return
3	791 (RD/PK)	Fuel tank pressure transducer sensor

C438

18C620



F02235

14A005



F02073