

rear door

14632	C 1	C820b	E 5
14633	C 1	M64 . Door lock actuator, left rear	E 2
C701	C 5	M65 . Door lock actuator, right rear	E 1
C702	A 4	M116 Power window motor, left rear	F 3
C703	F 3	M117 Power window motor, right rear	F 2
C704	E 2	N110 . Window adjust switch, right rear	C 5
C715a	F 4	N111 . Window adjust switch, left rear	C 5
C715b	E 5	N237 . Door ajar switch, driver side rear	F 4
C801	C 5	N237 . Door ajar switch, driver side rear	E 5
C802	A 3	N238 . Door ajar switch, passenger side rear	F 3
C803	F 2	N238 . Door ajar switch, passenger side rear	E 5
C804	E 2	Y17 . . Speaker, left rear	A 3
C820a	F 3	Y19 . . Speaker, right rear	A 3