Ground points — Cell 151

	Location	Page/coordinates
G103	engine, RH side, bottom	4 – E 3
G105	engine, front, RH side	4 – E 4
G108	engine, front, RH side	4 – E 4
G200	corner of support wall, bottom, Left	7 – F 1
G204	corner of support wall, bottom, Left	7 – F 1
G401	vehicle rear end, RH side	10 – C 1