C456

14401

N278
Ignition switch



F07050

Pin	Circuit	Circuit Function
1	15-DA1 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected)
2	30S-LE29 (RD/GN)	Voltage supplied at all times (not overload protected), switched
3	31S-TA32 (BK/WH) +	Ground, switched
	31S-TA34 (BK/YE)	Ground, switched
4	30-BB9A (RD)	Voltage supplied at all times (not overload protected)
	30-BB9 (RD)	Voltage supplied at all times (not overload protected)
5	30S-TA31 (RD/BK)	Voltage supplied at all times (not overload protected), switched
6	75-DA1 (YE)	Voltage: Ignition switch in Accessory or Run
7	50-BB16 (GY/BK)	Voltage, ignition switch in Start (not overload protected)
	50-BB17 (GY/OG)	Voltage, ignition switch in Start (not overload protected)