66-3 WARNING CHIME

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C216	13-25
C280	59-7
C283	59-7
C287	62-7
C288	62-7

REVISED



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.