C946

14405

F01013



R19
Rear window defrost
grid

Pin	Circuit	Circuit Function
1	31-HB19 (BK)	Ground

C947

14405

F01005

R19
Rear window defrost
grid

Pin	Circuit	Circuit Function
1	15S-HB19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected)

C949 (BK)

14A584

F01015

R19
Rear window defrost
grid

Pin	Circuit	Circuit Function
1	15S-HB19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched

C950

14A584

F01015

R19
Rear window defrost
grid

Pin	Circuit	Circuit Function
1	15S-HB19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched

C951

14405

F01015

R19
Rear window defrost
grid

Pin	Circuit	Circuit Function
1	31-HB19 (BK)	Ground

C954 (BK)

9H589, 12A690

N17
Oil pressure switch



F01016

Pin	Circuit	Circuit Function
1	31S-GC20 (BK/OG)	Ground, switched

C957

14K733

Y16
A/C Compressor
clutch



F02271

Pin	Circuit	Circuit Function
1	15S-FA6 (GN/YE)	Voltage, ignition switch in Start or Run (not overload protected), switched
2	31-FA6 (BK)	Ground