C1006

14K733

K36
Low beam relay



F20012

Pin	Circuit	Circuit Function
1	15S-LE19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched
	15S-LD8 (GN/RD) +	Voltage, ignition switch in Start or Run (not overload protected), switched
	15S-LE19 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched
2	91-LE19 (BK/BU)	Ground
3	30-LE20 (RD)	Voltage supplied at all times (not overload protected)
4	–	not used
5	15S-LE20 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected), switched
	15S-DC16 (GN/BU) +	Voltage, ignition switch in Start or Run (not overload protected), switched
	15S-DC17 (GN/BU)	Voltage, ignition switch in Start or Run (not overload protected), switched

C1007

14K733

K4
Fuel pump relay



F20012

Pin	Circuit	Circuit Function
1	15-RH6 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected)
2	91-RH5 (BK/BU)	Ground
3	30-RH6 (RD)	Voltage supplied at all times (not overload protected)
4	–	not used
5	15-RP3 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected)