

left front door

14631	B 2	C526b	A 5
A244 . Key pad switch assembly	A 3	C527	C 5
C500 - Before Jan 31	A 3	C530 . - As of Jan 31	A 3
C504a	F 3	M80 . Power window motor, driver side front	C 1
C504b	E 4	M220 Exterior rear view mirror, driver side	F 3
C505	E 5	M225 Door lock actuator, driver side	A 2
C510	E 1	N204 . Door lock switch, driver side	E 5
C520	F 4	N239 . Door ajar switch, driver side front	A 5
C521	F 3	N239 . Door ajar switch, driver side front	A 4
C523	D 1	N409 . Exterior rear view mirror switch	C 5
C524	C 1	N447 . Master window adjust switch	F 3
C525	A 2	N447 . Master window adjust switch	E 4
C526a	A 4	Y28 . . Speaker, left front	D 1