Components	Location	Cell 151 Page/coordinates
F1.16	in Battery Junction Box (BJB)	
F1.18	in Battery Junction Box (BJB)	
F1.20	in Battery Junction Box (BJB)	
F1.21	in Battery Junction Box (BJB)	
F1.22	in Battery Junction Box (BJB)	
F1.23	in Battery Junction Box (BJB)	
F1.24	in Battery Junction Box (BJB)	
F1.25	in Battery Junction Box (BJB)	
F1.26	in Battery Junction Box (BJB)	
F1.27	in Battery Junction Box (BJB)	
F1.29	in Battery Junction Box (BJB)	
F2.1	in Central Junction Box (CJB)	
F2.4	in Central Junction Box (CJB)	
F2.5	in Central Junction Box (CJB)	
F2.6	in Central Junction Box (CJB)	
F2.7	in Central Junction Box (CJB)	
F2.9	in Central Junction Box (CJB)	
F2.10	in Central Junction Box (CJB)	
F2.11	in Central Junction Box (CJB)	
F2.12	in Central Junction Box (CJB)	
F2.13	in Central Junction Box (CJB)	
F2.14	in Central Junction Box (CJB)	
F2.15	in Central Junction Box (CJB)	
F2.16	in Central Junction Box (CJB)	
F2.17	in Central Junction Box (CJB)	
F2.19	in Central Junction Box (CJB)	
F2.21	in Central Junction Box (CJB)	
F2.25	in Central Junction Box (CJB)	
F2.26	in Central Junction Box (CJB)	
F2.31	in Central Junction Box (CJB)	
F2.32	in Central Junction Box (CJB)	
F2.35	in Central Junction Box (CJB)	
F2.38	in Central Junction Box (CJB)	
F2.41	in Central Junction Box (CJB)	
K4	Fuel pump relay in Battery Junction Box (BJB)	5 – B 2
K5	Daytime Running Lamps (DRL) relay in Battery Junction Box (BJB)	5 – B 2
K22	Starter relay (11450) behind radiator grille, RH side	3 – A 5
K33	Horn relay in Battery Junction Box (BJB)	5 – A 2
K53	Headlamp relay Auxiliary relay box 1	6 – E 1
K73	Blower motor relay in Battery Junction Box (BJB)	5 – B 1
K107	A/C clutch relay in Battery Junction Box (BJB)	5 – A 2
K142	Interior lamp relay in Central Junction Box (CJB)	9 – E 1
K153	Wiper relay, low speed Supplied by body builder	
K154	Wiper relay, high speed Supplied by body builder	
K163	PCM power relay in Battery Junction Box (BJB)	5 – B 1
K319	Trailer exterior lamp relay Auxiliary relay box 1	6 – E 1
K347	Turn relay, left in Central Junction Box (CJB)	9 – E 2
K348	Turn relay, right in Central Junction Box (CJB)	9 – E 2
K357	Trailer tow relay, reversing lamp Auxiliary relay box 1	6 – E 1
K374	Hydro max relay engine compartment, LH side	5 – B 5