C94 (WH)

14K733

B15
Wheel speed sensor, left front

F02005

Pin	Circuit	Circuit Function
1	8-CF32 (WH)	Sensor signal
2	9-CF32 (BN)	Sensor signal return (reference/ground)

C95 (WH)

14K733

B14
Wheel speed sensor, right front

F02005

Pin	Circuit	Circuit Function
1	8-CF38 (WH/RD)	Sensor signal
2	9-CF38 (BN/RD)	Sensor signal return (reference/ground)

C97 (WH)

14014

B17
Wheel speed sensor, left rear

F02005

Pin	Circuit	Circuit Function
1	8-CF34 (WH/BU)	Sensor signal
2	9-CF34 (BN/BU)	Sensor signal return (reference/ground)

C98 (WH)

14014

B16
Wheel speed sensor, right rear

F02005

Pin	Circuit	Circuit Function
1	8-CF40 (WH/GN)	Sensor signal
2	9-CF40 (BN/GN)	Sensor signal return (reference/ground)

C102 (GN)

14K733

F16030



(7) 31-CF28 (BK)
31S-CF28 (BK/RD)

14K024

F16029