120-1 POWER SEATS

For diagnostic information, refer to Section 501-10 of the Workshop Manual.



Contains three reversible motors. Direction of motors is determined by Driver's Switch.

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.