Seat adjust switch, driver side front (14A701) (continued)

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Forward/Rearward circuit	2 and 3	Forward	Closed circuit
		Rearward	Open circuit
	2 and 8	Forward	Open circuit
		Rearward	Closed circuit
	3 and 4	Rest	Closed circuit
	8 and 4		
Front up/down circuit	2 and 7	Up	Closed circuit
		Down	Open circuit
	2 and 5	Up	Open circuit
		Down	Closed circuit
	7 and 4	Rest	Closed circuit
	5 and 4		
Rear up/down circuit	2 and 1	Up	Closed circuit
		Down	Open circuit
	2 and 6	Up	Open circuit
		Down	Closed circuit
	4 and 4	Rest	Closed circuit
	6 and 4		
Forward/Rearward Recliner Circuit	2 and 7 2 and 1	Up	Closed circuit
		Down	Open circuit
	2 and 5 2 and 6	Up	Open circuit
		Down	Closed circuit
	7 and 4	Rest	Closed circuit
	5 and 4		
	6 and 4		
	1 and 4		