
1 2 3 4 5 6 7 8 9 10
A
B
C
D
E
F
C147
C149
THROTTLE POSITION
(TP) SENSOR
C127
BRAKE PRESSURE
SWITCH
C189
ANTI-THEFT
HOOD SWITCH
C116
SPEED CONTROL
SERVO
C123, C133
GENERATOR
C176 TO C181
MASS AIR
FLOW (MAF)
SENSOR
C117
WASHER FLUID
LEVEL SWITCH
C118
LIFTGATE
WASHER PUMP
MOTOR
C132
COOLING FAN
DROPPING
RESISTOR
DO NOT USE
THIS ILLUSTRATION
AND GRID FOR
REPORTING VEHICLE
REPAIR LOCATIONS
C119
WINDSHIELD
WASHER PUMP
MOTOR
C182
AMBIENT AIR
TEMPERATURE
SENSOR
C172
A/C CLUTCH
FIELD COIL
C148
IDLE AIR CONTROL
(IAC) VALVE
FRONT OF VEHICLE
WINDSTAR
FCS–12255–01 (2 OF 11)

ENGINE (2 OF 4)