

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C242	13-29
C243	13-28

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.