Excursion

Item	Part Number	Description
1	12A581	Wiring harness – Engine control sensor
2	12B637	Wiring harness – Engine control sensor and fuel charge
3	12A690	Wiring harness – Engine control sensor extension
4	14B060	Wiring harness – Starter motor relay and battery ground
5	14300	Wiring harness – Battery output
6	14305	Wiring harness – Alternator to battery
7	14B060	Wiring harness – Starter motor relay and battery ground
8	14401	Wiring harness – Main
9	14A005	Wiring harness – Body main
10	14A699	Wiring harness – Seat regulator – with memory
	14B084	Wiring harness – Seat regulator – without memory
11	14B084	Wiring harness – Seat regulator
12	15525	Wiring harness – Powertrain Transmission Control Systems
13	14B079	Wiring harness – Center console
14	14A504	Wiring harness – Body main
15	14335	Wiring harness – Interior illumination
16	14334	Wiring harness – Interior lamps

Item	Part Number	Description
17	14405	Wiring harness – Tail lamps
18	13A576	Wiring harness – Trailer lamp feed
19	14086	Wiring harness – Door warning switch
20	13A625	Wiring harness – High mounted stoplamp
21	13K027	Wiring harness – DTRL kit
22	13A409	Wiring harness – Tail lamps
23	–	ABS control module (2C219)
24	–	Battery (10655)
25	–	Battery II
26	–	Auxiliary relay box 1
27	–	Auxiliary relay box 2
28	–	Powertrain Control Module (PCM) (12A650)
29	–	Central Junction Box (CJB) (14A068)
30	–	Vehicle Security Module (VSM)
31	–	Electronic Automatic Temperature Control (EATC) module (19980)
22	–	Four–wheel drive control module
33	–	Parking Aid Module (PAM) (15K866)