

CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C224	60-7
C227	13-29



Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.