

Cell 12 – Charging System

Cell 20 – Starting System

Cell 21 – Engine Ignition

Cell 23 – Engine Controls – 3.8L

Cell 24 – Engine Controls – 4.6L 2V

Cell 25 – Engine Controls – Cobra

Cell 26 – Engine Controls – Mach1

Cell 31 – Vehicle Speed Control

Cell 33 – Cooling Fan

Cell 42 – ABS

Cell 81 – Wipers and Washers

Cell 46 – Air Bags

Cell 120 – Power Seats

Cell 122 – Power Lumbar Seats

Cell 89 – Courtesy Lamps

Cell 103 – Convertible Top

Cell 56 – Rear Window Defrost

Cell 113 – Luggage Compartment Lid Release

Cell 90 – Turn/Stop/Hazard Lamps

Cell 92 – Exterior Lamps

Cell 93 – Reversing Lamps

Cell 100 – Power Windows

Cell 110 – Power Door Locks

Cell 124 – Power Mirrors

Cell 111 – Remote Keyless Entry (RKE)

Cell 14 – Module Communications Network

Cell 60 – Instrument Cluster

Cell 37 – Shift Lock

Cell 44 – Horn/Cigar Lighter

Cell 54 – Air Conditioner/ Heater

Cell 59 – Multifunction Electronic Control Modules

Cell 66 – Warning Devices

Cell 71 – Illumination

Cell 112 – Anti–Theft

Cell 130 – Radio

Cell 85 – Headlamps

Cell 86 – Fog Lamps

Cell 90 – Turn/Stop/Hazard Lamps

Cell 92 – Exterior Lamps

Cell 97 – Daytime Running Lamps

Cell 29 – Transmission Controls