Multifunction Switch

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Flash–to–pass	196 and 12	Pull and hold lever stalk toward steering wheel	Closed circuit
High beam	12 and 15	Lever stalk in detent away from steering wheel	Closed circuit
Low beam	15 and 13	Lever stalk in detent toward steering wheel	Closed circuit
Stoplamps	511, 5 and 9	Hazard switch to Normal (Off) and Turn switch to Neutral	Closed circuit
Turn signals	44, 9 and 3	Hazard switch to Normal (Off) and Turn switch to Left	Closed circuit
	44, 5 and 2	Hazard switch to Normal (Off) and Turn switch to Right	Closed circuit
Hazard	44, 2, 3, 5 and 9	Hazard switch to Hazard (On) (Button pushed in and then released to fully extended position)	Closed circuit