C242

14401

N114
Fog lamp switch



F08177

Pin	Circuit	Circuit function
1	1347 (DB/WH)	Fog lamp switch, output
2	13 (RD/BK)	High beam lamp, output
3	–	not used
4	57 (BK)	Ground
5	–	not used
6	478 (TN/OG)	Fog lamp switch, to front fog lamp
7	–	not used
8	19 (LB/RD)	Instrument illumination, feed

C248

14405



F04239

7M196



F04241