C312

14A005



F14058

14A005



F14056

C319

14B079

R42
Cigar lighter, front
(15055)



F03163

Pin	Circuit	Circuit function
1	40 (LB/WH)	Voltage supplied at all times (overload protected)
2	–	not used
3	57 (BK)	Ground

C323

14A699

N466
Safety belt buckle
switch, driver



F02433

Pin	Circuit	Circuit function
1	85 (BN/LB)	Safety belt buckle switch (10B924), input
2	1558 (TN/BK)	Seat track position sensor, driver, Signal return

C327

14334



F08273

14A005



F08271