
1 2 3 4 5 6 7 8 9 10
A B C D E F
REVISED
C219 SPEED CONTROL/ HORN SWITCH ASSEMBLY
C250a, C250b, C250c INSTRUMENT CLUSTER
C290 ADJUSTABLE PEDAL SWITCH
C234
C296 FUNCTION SELECTOR SWITCH
C226 PASSENGER AIR BAG DEACTIVATION SWITCH
C237 POWER POINT
C245 (EXCURSION) C232 (PICKUP)
C279 BRAKE PEDAL POSITION (BPP) SWITCH
C220 PASSENGER AIR BAG
C233
C276 PARK BRAKE SWITCH
C271 INERTIA FUEL SHUTOFF (IFS) SWITCH
C1049
C1050
C1051
G200, G203
DO NOT USE THIS ILLUSTRATION AND GRID FOR REPORTING VEHICLE REPAIR LOCATIONS
EXCURSION, SUPER DUTY SERIES FCS–12254–01 (8 OF 20)
C224 DRIVER AIR BAG
C269 IGNITION SWITCH
G201, G202
C218
C270 RESTRAINTS CONTROL MODULE (RCM) (JOB 1 + 90)
C223 AIR BAG DIAGNOSTIC MODULE
I/P RELAY BLOCK
C225, C298 FUNCTION SELECTOR SWITCH
C222 (EXCURSION) C239 (PICKUP)
FRONT OF VEHICLE

I/P VIEW (1 OF 2)