
Name of component
Ignition switch
(11572)
0) Off
1) Acc
2) Run
3) Start
Details about component or operation
3 C300
Component connector number
Switches that move together
Dashed line shows a mechanical connection between switches
Normally open contact When coil is energized, switch is pulled closed
One pole, two position switch
Fuse condition
Hot at all times
F23
3A
Central Junction Box (CJB)
(14A068)
Name of component
Base part number
720 20 RD/YE
5 C220
Instrument cluster
6) Illumination
Details about component or operation
6
4 C220
Splice
See page 13–1
Reference to page where circuit is shown complete
Component connector number
S64
19 20 LB/RD
17 C175
Powertrain Control Module (PCM)
(12A650)
33 19 C175
57 20 BK 57 20 BK
Wire insulation is one color
Dashed line indicates terminals for the same connector
4 2 C201
S101
See page 10–1
G1002
G1001
Ground numbered for reference to component location chart
Other circuits which are also grounded at G1001, but are not shown, can be found using the reference