F1, F2

-1


30
F1
7.5A
15
F2
15A
P93
Battery Junction Box (BJB)
15) Hot in start or run
30) Hot at all times
LG01
1.25 OG
AV75
2 BK/RD
3
C1007
K26
Fog lamp relay
3
C182
K4
Fuel pump relay
P51
Engine compartment relay box