
FROM S296
(W/ENTERTAINMENT SYSTEM)
PAGE 13-31
OR
FROM S221
(W/O ENTERTAINMENT SYSTEM)
PAGE 13-10
* W/GROTE LAMP, REAR HEADLINER
M
54 LG/YE
C301M
C301F
151–17 A9
W/O FULL HEADLINER
W/FULL HEADLINER
54 LG/YE
54 LG/YE
S302
54 LG/YE
54 LG/YE
TO C303
PAGE 13-12
151–17 A8
C300M
C300F
WAGONS W/AUX A/C
WAGONS W/O AUX A/C
54 LG/YE
54 LG/YE
54 LG/YE
S405
S912
54 LG/YE
54 LG/YE
C414M
C414F
54 LG/YE
54 LG/YE
*C915F
*C915M
54 LG/YE
54 LG/YE
C411
C411
C904
C900
C900
HIGH MOUNTED STOPLAMP
PAGE 89-3
REAR COURTESY LAMP SWITCH
PAGE 89-3
HIGH MOUNTED STOPLAMP
PAGE 89-3
INTERIOR SWITCH/LAMP
PAGE 89-4
CARGO LAMP
PAGE 89-4
CARGO LAMP
PAGE 89-4