C156 (GN)

12B637

Y111
Injector 4 (9F593)



F02137

Pin	Circuit	Circuit function
1	AV62 (YE/VT)	Injector 4, control
2	AV84 (YE)	Voltage supplied at all times (overload protected)

C157 (BK)

12B637

Y113
Injector 6 (9F593)



F02137

Pin	Circuit	Circuit function
1	AV64 (GY/BU)	Injector 6, control
2	AV86 (YE)	Voltage supplied at all times (overload protected)

C159 (GY)

7A488

B22
Mass Air Flow
(MAF) sensor
(12B579)



F04044

Pin	Circuit	Circuit function
1	AV16 (WH/BU)	Mass Air Flow (MAF) sensor (12B579), signal, return
2	AV17 (BU/OG)	Mass Air Flow (MAF) sensor (12B579), output
3	AV74 (BK/WH)	Voltage supplied in Start and Run (overload protected)
4	–	not used

C160

14A103

E42
Fog lamp, right front
(15200)



F02359

Pin	Circuit	Circuit function
1	LG03 (OG/BK)	Fog lamp relay, switched power
2	LGE2 (BK)	Ground

C161 (BK)

7A488

B99
Transmission
Range (TR) sensor



F10065

Pin	Circuit	Circuit function
1	ZY50 (LG)	Voltage supplied in Start and Run (overload protected)
2	ST03 (LG/BK)	Voltage supplied with park/neutral
3	ST04 (LG)	Voltage supplied in Start and Run (overload protected)
4	ZY51 (BU)	Voltage supplied with park/neutral
5	ZY20 (BU/RD)	Voltage supplied in reverse
6	–	not used
7	ZY16 (BU/BK)	Voltage supplied in 1st
8	ZY17 (BU/YE)	Voltage supplied in 2nd
9	ZY19 (BU)	Voltage supplied with park/neutral
10	ZY18 (BU/WH)	Voltage supplied in drive