DAYTIME RUNNING LAMPS (DRL) 97-2



CONNECTOR REFERENCE LIST

CONNECTOR	SECTION-PAGE
C238	62-6
C242	13-29
C243	13-28
C246	13-26
C259	85-3

Refer to Location Index, Cell 152, for Component, Connector, Splice, Ground and Base Part Number descriptions and locations.