C218b

14401

A216
Steering wheel assembly



F10067

Pin	Circuit	Circuit Function
1	9-LG43 (BN/WH)	Sensor signal return (reference/ ground)
2	8-LE14 (WH/BU)	Sensor signal
3	8-LG43 (WH/VT)	Sensor signal
4	7-KA19 (YE/BK)	Voltage D.C. supplied at all times (sensor)
5	10-KA19 (GY/BK)	Signal 2 (Y–direction, reverse, downward)
6	8-KA19 (WH/BK)	Sensor signal
7	9-AL10 (BN)	Sensor signal return (reference/ ground)
8	8-AL10 (WH)	Sensor signal
9	–	not used
10	8-MC8 (WH/RD)	Sensor signal

C218c

14401

A216
Steering wheel assembly



F03035

Pin	Circuit	Circuit Function
1	30S-JA8 (RD/OG)	Voltage supplied at all times (not overload protected), Switched
2	–	not used
3	31S-JA8 (BK/OG)	Ground, Switched

C219

14401



F08173

19A657



F08171