
* LIMOUSINE
All Circuits are 57 BK unless otherwise noted.
LIGHTING CONTROL MODULE (LCM)
PAGE 58-3
MESSAGE CENTER SWITCH MODULE
PAGE 63-2
FUEL TANK ASSEMBLY
PAGE 23-4
FUEL PUMP/ FUEL GAUGE SENDER
SPEED CONTROL SERVO
PAGE 31-2
FRONT RADIO CONTROL UNIT
PAGES 130-1, 130-2
INSTRUMENT CLUSTER
PAGE 63-4
PASSIVE ANTI-THEFT SYSTEMS (PATS) TRANSCEIVER MODULE
PAGE 112-1
DAY/NIGHT SENSOR/ AMPLIFIER
PAGE 87-1
23
13
1
10
2
10
1
1
C221
C222
C264
C464M
C464F
C123
C257
C255
C209
C286
676 PK/OG
151–5 C1
* C326F
* C326M
151–6 D10
C201M
C201F
151–5 C1
C223F
C223M
EXECUTIVE
S210
TO G203
PAGE 10-5