
K347
Turn relay, left
95–3
K348
Turn relay, right
95–3
K356
Trailer tow relay, parking lamp
95–4
K69
Fuel heater relay
27–3
K500
Neutral start switch relay
20–3
P93
Battery Junction Box (BJB)
(14A003)
2 C1192
2 C1193
86 C1199
85 C1329
2 C1331
57 18 BK
all others
Powerstroke
K357
Trailer tow relay, reversing lamp
95–4
K132
Stop lamp relay
95–5
K383
ABS relay
42–4
K502
VP–44 relay
24–2
K501
Shift control modulator relay
30–3
K163
PCM power relay
25–3
2 C1178
2 C1250
85 C1255
2 C1333
1 C1332
85 C1016
with air brakes
Cummins
Cat
Powerstroke
V7
A/C Compressor clutch diode
54–5
K399
Stop lamp relay 2
90–7, 90–8
1 C1068
2 C1330
S107
A
See page 10–2
Powerstroke