Master window/door lock/unlock switch (continued)

Component testing procedure

Circuit to test	Connect self–powered test light or ohmmeter to terminals	Move switch to these positions	A good switch will indicate
Power and Ground Checks Before Any Other Tests	8 (C508a) and 6 (C508a) 2 (C508a) and 6 (C508a)	All switches, all positions	Open circuit
	6 (C508a) and 1, 3, 5, 7 (508a) 6 (C508a) and 1, 3, 5, 7 (508b)	All switches, at rest	Closed circuit
Left front window circuit	8 (508a) and 7 (508a)	Up	Closed circuit
	8 (508a) and 3 (508a)	Down	Closed circuit
Right front window circuit	2 (508a) and 1 (508a)	Up	Closed circuit
	2 (508a) and 5 (508a)	Down	Closed circuit
Left rear window circuit	8 (508a) and 1 (508b)	Up	Closed circuit
	8 (508a) and 4 (508b)	Down	Closed circuit
Right rear window circuit	8 (508a) and 6 (508b)	Up	Closed circuit
	8 (508a) and 3 (508b)	Down	Closed circuit
One–Touch Down Switch	8 (508a) and 4 (508a)	One–Touch Down Switch	Closed circuit