C31 (BK)

14014



F10048

Pin	Circuit	Circuit Function
1	–	not used
2	–	not used
3	–	not used
4	–	not used
5	15S-JA34 (GN/OG)	Voltage, ignition switch in Start or Run (not overload protected), switched
6	91S-JA34 (BK/RD)	Ground, switched
7	–	not used
8	–	not used
9	15S-JA15 (GN/RD)	Voltage, ignition switch in Start or Run (not overload protected), switched
10	91S-JA15 (BK/OG)	Ground, switched