Function Codes -9

Number	Basic color	Description
1	WH	Audio signal positive
2	GY	Audio signal negative
3	BN	Audio signal reference (return/shield)
4	GY	Data link, bus positive
5	BU	Data link, bus negative
6	NO	Data link, bus shield
7	YE	Voltage D.C. supplied at all times (sensor)
8	WH	Sensor signal
9	BN	Sensor signal return (reference/ground)
10	GY	Signal 2 (Y–direction, reverse, downward)
14	VT	Voltage supplied in Start and Run (overload protected)
15	GN	Voltage, ignition switch in Start or Run (not overload protected)
20	PK	Voltage, hot in run only
29	OG	Voltage supplied at all times (overload protected)
30	RD	Voltage supplied at all times (not overload protected)
31	BK	Ground
32	WH	Switched between: Battery voltage, Ground or Open
33	YE	Switched between: Battery voltage, Ground or Open
34	BU	Switched between: Battery voltage, Ground or Open
35	VT	Switched between: Battery voltage, Ground or Open