Power mirror adjust switch -16

Schematic



Terminal locations