86-1 FOG LAMPS

For diagnostic information, refer to Section 417-01 of the Workshop Manual.