Item	Part Number	Description
1	12A581	Wiring harness – Engine control sensor
2	12A690	Wiring harness – Engine Control
3	12B637	Wiring harness – Engine control sensor and fuel charge
4	14305	Wiring harness – Alternator
5	14401	Wiring harness – Main wiring harness
6	13A576	Wiring harness – Trailer lamp feed
7	14405	Wiring harness – Rear lamp
8	14A005	Wiring harness – Body Main
9	14A320	Wiring harness – Headlamp dimmer switch jumper
10	15525	Wiring harness – Reversing lamps switch to Rear lamp feed
11	14B079	Wiring harness – Console Panel
12	14B084	Wiring harness – Front seat, passenger side
13	14C719	Wiring harness – Seat control feed jumper
14	14334	Wiring harness – Interior lamp feed
15	13A625	Wiring harness – High mounted stoplamp
16	14A504	Wiring harness – Body Main
17	14A699	Wiring harness – Seat control feed jumper
18	14A227	Wiring harness – Luggage compartment, jumper
19	13A409	Wiring harness – Rear lamp Connector
20	14N139	Wiring harness – Reversing lamp
21	13412	Wiring harness – Rear license plate lamp
22	18B518	Wiring harness – Heater blower motor, front
23	2C219	ABS control module (2C219)
24	14A003	Battery Junction Box (BJB) (14A003)
25	14A067	Central Junction Box (CJB) (14A068)
26	12A690	Powertrain Control Module (PCM) (12A650)
27	15604	Central Security Module (15604)
28	14B205	Generic Electronic Module (GEM) (14B205)
29	873	Auxiliary relay box 1
30	14B321	Restraints control module (14B321)
31	1166	Auxiliary relay box 2
32	10E887	Audio Visual Navigation (AVN) module (10E887)
33	14C708	Driver seat module (14C718)
34	14B450	Tonneau cover control module (14B450)