


**C204**
**RESTRAINT CONTROL MODULE (RCM)**

| PIN | CIRCUIT | CIRCUIT FUNCTION |
|---|---|---|
| 1 | 298 (VT/OG) | Power (Hot in Run) |
| 2 | 615 (GY/WH) | Driver Air Bag Return |
| 3 | 614 (GY/OG) | Driver Air Bag Feed |
| 4 | 70 (LB/WH) | Diagnostic to Data Link Connector (DLC) |
| 5 | 616 (PK/BK) | Passenger Air Bag Return |
| 6 | 607 (LB/OG) | Passenger Air Bag Feed |
| 7 | 57 (BK) | Ground |
| 8 | 57 (BK) | Ground |
| 9 | 608 (BK/YE) | Air Bag Indicator Driver |
| 10 | 57 (BK) | Ground |
| 11 | 1083 (LB/BK) | Tone Generator |

**CONNECTOR REFERENCE LIST**

| CONNECTOR | SECTION-PAGE |
|---|---|
| C221 | 58-4 |
| C226 | 14-4 |
| C254 | 63-5 |