

C324

DRIVER TEMPERATURE CONTROLLED SEAT SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	–	NOT USED
2	1255 (WH/RD)	Driver Seat Enable
3	–	NOT USED
4	1019 (TN/LB)	Driver Temp Adjust (–)
5	1018 (LG/OG)	Driver Temp Adjust (+)
6	–	NOT USED
7	1551 (PK/WH)	Switch to Module
8	1550 (WH/OG)	Switch to Module



C325

PASSENGER TEMPERATURE CONTROLLED SEAT SWITCH

PIN	CIRCUIT	CIRCUIT FUNCTION
1	–	NOT USED
2	1255 (WH/RD)	Passenger Seat Enable
3	–	NOT USED
4	1019 (TN/LB)	Passenger Temp Adjust (–)
5	1018 (LG/OG)	Passenger Temp Adjust (+)
6	–	NOT USED
7	1551 (PK/WH)	Switch to Module
8	1550 (WH/OG)	Switch to Module